

IMPORTANT: Remove product from water before charging.

Do not turn product on while charging.

Failure to follow instructions can cause severe and/or fatal injury.

NOTE: This product should be operated in at least 12 inches of water to get the maximum water height. It is recommended to clean out the filter screen at bottom of unit periodically to ensure proper water flow.

GETTING STARTED


IMPORTANT: Before first use, the battery must be fully charged. This may take up to 6 hours. When fully charged, the red light on the bottom of the product will turn off.

Always make sure the product is thoroughly dry before charging.

1. Plug the charge cable into a USB port or any standard 5V 1A or 5V 2A USB wall adapter.
2. Remove the charging port plug on top of the product and plug the cable into the port (the red light on the bottom of the product will turn on).
3. When finished charging, (the red light will turn off), unplug the charge cable from the charging port.
4. Replace the charging port plug, pressing it firmly into place so water does not seep into the port when in use.

OPERATION

- Press the power button to turn on the fountain and underwater light show.
- To change the fountain mode, press the power button again. There are 3 modes: consistent maximum height, gradual buildup to maximum height and random sprays of varying heights
- To turn the product off, press and hold the power button approximately 3 seconds and release. The product will then turn off.



NOTE: Product automatically shuts off after one (1) hour.

WARNING: SEIZURES - PEOPLE WITH PHOTOSENSITIVE EPILEPSY CAN HAVE SEIZURES TRIGGERED BY FLICKERING OR FLASHING LIGHTS SUCH AS STROBE OR DISCO LIGHTS.

KEEP OUT OF REACH OF CHILDREN. THIS IS NOT INTENDED AS A TOY.

The Underwater Light Show and Fountain incorporates a safety feature to protect it from potential damage. If the product becomes hot due to extreme conditions, it will vary the speed of the water pump to prevent overheating and cause the water height to vary. This is normal and the fountain will return to regular operating once the temperature has subsided.

CLEANING & MAINTENANCE

Wipe dry with a soft cloth after use.

To clean debris from the fountain intake on the bottom of the product, rinse the screen under running water. Brush gently with a soft bristle brush.

STORAGE

When the product is out of water, it should be stored in a cool, dry place. Do not leave the product in direct sunlight when not in use as this could damage the batteries. Do not store under heavy objects.

IMPORTANT: Remove from pool when not in use or while cleaning so unit is not damaged by skimmers or other devices. Do not submerge unit in water as this could damage the electronic components.

IMPORTANT: The batteries are permanently sealed in the product and cannot be removed or replaced. Attempting to remove and/or replace the batteries will void the warranty.

IMPORTANT: Contains lithium batteries. If product becomes damaged or cracked DO NOT place it into water.

NOTE!

- Do not mix old and new batteries.
- Do not dispose batteries into fire. Batteries may explode or leak.
- Do not mix alkaline standard (carbon-zinc), or rechargeable (nickel-cadium) batteries.
- Replace batteries ensuring the correct battery type, and as a simultaneous act.
- Remove batteries if product is to be left unused for a long time.
- Clean the battery contacts and also those of the devices prior to battery installation.
- The supply terminal is not to be short circuited (+) (-).
- Non-rechargeable batteries are not to be recharged.
- Batteries are to be inserted with the correct polarity.
- Remove exhausted batteries promptly and dispose of properly.

CAUTION: Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.

This Class B digital apparatus complies with Canadian ICES-003.

LIMITED WARRANTY STATEMENT

General Terms This Limited Warranty applies to the product enclosed ("the Product") distributed by Great American Duck Races, Inc., an Arizona corporation, doing business as Great American Marketing and Events ("GAME"), sold with this Limited Warranty Statement. This Limited Warranty is applicable in all countries. • GAME warrants that the Product you have purchased from GAME is free from defects in materials or workmanship under normal use during the warranty period. The warranty period starts on the date of purchase and continues for ninety (90) days. Your dated sales or delivery receipt, showing the date of purchase of the Product, is your proof of the purchase date. • During the warranty period, GAME will repair or replace any defective parts with new parts, or, at GAME's discretion, used parts that meet or exceed performance specifications for new parts. All parts removed under this warranty become the property of GAME. The replacement part takes on the warranty status of the removed part or product. • This Limited Warranty does not apply to expendable parts. This Limited Warranty does not extend to any product from which the serial number has been removed or that has been damaged or rendered defective (a) as a result of accident, misuse, abuse or other external causes; (b) by operation outside the usage parameters stated in the Instruction Sheet that shipped with the Product; (c) by the use of parts not manufactured or sold by GAME; or (d) by modification or service by anyone other than GAME.

Limitation of Liability GAME is not liable for any damages caused by the Product or the failure of the Product to perform, including any direct or indirect damages for personal injury, lost profits, lost savings, incidental damages, consequential damages, or any other pecuniary loss arising out of the use or inability to use the Product. GAME is not liable for any claim made by a third party or made by you for a third party. • This limitation applies whether damages are sought, or a claim made, under this Limited Warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation cannot be waived or amended by any person. This limitation of liability will be effective even if you have advised GAME or an authorized representative of GAME of the possibility of any such damages.

EXCEPT AS EXPRESSLY SET FORTH IN THIS LIMITED WARRANTY, GAME MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. GAME EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS WORLDWIDE LIMITED WARRANTY STATEMENT.

To obtain warranty service, please call, write, or email us directly at the address shown below.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

WARNING: GAME™ has in the past, and will in the future, take any and all legal steps necessary in order to protect our proprietary trademarks, patents, trade dress, and copyrights. This applies to, but is not limited to, products, product design, graphics, packaging and literature. We will prosecute to the fullest extent of the law any persons or entities who infringe upon these rights.



Great American Merchandise & Events™
16444 N. 91st Street
Scottsdale, AZ 85260-1567 USA

tel: 888.382.5988
fax: 602.957.7665
U.S. Patent #s 7,413,319 & 7,717,582

email: products@game-group.com
www.game-group.com

